




## Ifm Programmable 4.3” HMI Controller for Industrial Systems

Requirements .....	2
Hardware overview .....	3
Firmware Installation.....	4
ifm ecomat Display Package Installation.....	5
Install Codesys Package .....	5
Create a new Codesys Project .....	6
Go Online with the Project and Controller.....	9

## Requirements

1. Install the latest Codesys x64 from Codesys website (admin rights required) – SP19 runtime.  
<http://us.store.codesys.com>
2. Download ecomat display firmware and package on ifm website.  
<https://www.ifm.com/us/en/product/CR1140?tab=documents>



3. Controller programming, set up and support videos  
<https://www.ifm.com/us/en/us/industrial-controls---i4.0/setup-and-support/setup-and-support>
4. Codesys online training courses  
<https://us.store.codesys.com/events.html>

### a. Codesys V3 Essential Training (for beginners – no programming background)



CODESYS V3 Essentials Training - LIVE ONLINE - Jan 2023  
2108100015-T-2023-01-23  
**\$1,000.00**

[More Details](#)

This 16-hour training is targeted for individuals who are new to CODESYS and need to get started with a good foundation. Through a mix of lectures and hands-on exercises, this class teaches the basic features and concepts of CODESYS and the IEC 61131-3 programming languages.  
[Learn More](#)

### b. Codesys V3 Intensive Training (for end users with PLC programming background)



CODESYS V3 Intensive Training - Beverly, MA - March 2023  
2108100012-T-2023-03-28  
**\$2,500.00**

Available: 2 of 10  
Mar 28, 2023 (08:00 EDT) - Mar 31, 2023 (17:00 EDT)  
Beverly, MA

[More Details](#)

This 30-hour training is targeted for experienced control engineers transitioning to CODESYS, or for engineers wishing to take their knowledge of CODESYS to the next level. It combines basic and advanced training modules to give participants a comprehensive understanding of the capabilities of CODESYS, alternating between lectures and hands-on labs. It includes hints, tricks, and best practices compiled from many years of experience.  
[Learn More](#)

## Hardware overview



M 12 A coded for power and CAN communication  
 Pin 1: Service (boot device into set up mode)  
 Pin2: 24 V DC  
 Pin 3: GND

Designation	M12 connector 1 (supply, CAN, service)	Operating voltage	Nominal value fuse	Required triggering characteristics
VBB <sub>30</sub>	pin 2	8...32 V DC	max. 3 A	$T_{fuse} \leq 120$ s at max. 6.25 A
Service input	pin 1	8...32 V DC	max. 3 A	$T_{fuse} \leq 120$ s at max. 6.25 A

## Firmware Installation

### 1. Recovery App


On delivery, the recovery app runs on the device.  
Current recovery app version is 1.0.0.7

### 2. Use local Recovery App

Use "INSTALL FROM FILE" to install \*.swu- or \*.upd-package from USB memory device.  
After successful installation, "RESTART" device.  
(Use "NETWORK SETUP" to change network parameters for web recovery app.)

### 3. Use Web Recovery App


Connect device to network.  
Enter device url: <http://192.168.82.245:8080>  
Select or drag & drop the \*.swu package here.




Wait until firmware is successfully loaded.  
Restart the device.

### 4. **Attention:** Launch Application

To start Codesys runtime, device application must be launch.

Press  to exit the setup mode.


- If a valid application program is saved: The application starts.
- If no valid application program is saved: A blank screen appears. Accessing the device with CODESYS is possible.



# ifm ecomat Display Package Installation


## Install Codesys Package

### 1. Open Codesys Installer with Administration Rights




### 2. Follow the steps below to install ecomat display codesys package.

CODESYS 3.5 SP19 (64 bit) Patch 5  
Patch 4




Select the correct package.




3 Select target package and follow prompt to install

### 3. Update all to latest packages



## Create a new Codesys Project


### 1. Open Codesys Installer



### 2. Create a new Project




### 3. Select an appropriate Template and give the project a Name




#### 4. Add libraries to current project



Open library manager



Select ifmEIP and click OK




#### 5. Add ethernet device to the ethernet tree




#### 6.

### Add an ethernet/IP Scanner



### Add an Ethernet module






## Go Online with the Project and Controller

### 1. Scan Device

Click 'Scan Network' if controller is connected directly to PC




Communication Settings **1** Scan Network Gateway Device **2** Enter IP if controller is connected to a switch.

Applications  
Backup and Restore  
Files  
Log  
PLC Settings  
PLC Shell  
Users and Groups  
Access Rights  
Symbol Rights  
Licensed Software Metrics  
Task Deployment  
IEC Objects  
Status  
Information

Gateway-1  
IP-Address: localhost  
Port: 1217

172.21.52.131 (active)  
Device Name: CR1140  
Device Address: 0301.1000.2DDC.AC15.3483  
Device IP Address: 172.21.52.131  
Target ID: 1063 0480  
Target Type: 4096  
Target Vendor: ifm electronic  
Target Version: 3.5.19.0

### 2. Set Ethernet Connection



Devices

CR Programmable Display  
Device (ecomatDisplay\_64bit)  
PLC Logic  
Application  
GlobalVariables  
TextLists  
ifmImagePool  
Library Manager  
PLC\_PRG (PRG)  
PLC\_PRG\_IN\_ST (PRG)  
Task Configuration  
ENIPScannerIOTask  
EtherNet\_IP\_Sca  
ENIPScannerService  
EtherNet\_IP\_Sca  
Task (IEC-Tasks)  
PLC\_PRG  
VISU\_TASK (IEC-Tas  
VisuElems. Visu\_F  
VisualizationManager  
Visu\_Default  
Communication (Communication)  
**1** Ethernet (Ethernet)  
EtherNet\_ecomatDisplay  
EtherNet\_IP\_Scane

Device Ethernet\_ecomatDisplay

General

Status

Ethernet Device I/O Mapping

Ethernet Device IEC Objects

Information

Network interface **2** Browse...

IP address 192 . 168 . 0 . 1

Subnet mask 255 . 255 . 255 . 0

Default gateway 0 . 0 . 0 . 0

Adjust operating system settings

Network Adapters

Interfaces

Name	Description	IP address
lo		127.0.0.1
eth0		172.21.52.131

**3** Select the correct IP setting

IP address 172 . 21 . 52 . 131

Subnet mask 255 . 255 . 254 . 0


Default gateway 172 . 21 . 52 . 1

MAC address 00:02:01:7F:32:9C



**4** OK Cancel

Double click on 'Ethernet\_ecomatDisplay4\_3'



Project gets update with the right settings.




### 3. Ethernet module set up




Assign input/output variable to array.




Generate Code to check for errors.




4. Go Online with the controller. ① Click 'Online' > 'Login'



Click the Start icon or F5 to start the application.



Green circles indicate everything is communicating.





For additional technical support, please reach out to us at [info.us@ifm.com](mailto:info.us@ifm.com) or call into 800-441-8246 and one of our technical engineers will be able to assist you with your questions.